

## 18W Hampton Floor Lamp

J92HBT J92BNT



### TUBE INSERTION / REPLACEMENT

- 1 Make sure that the lamp is not plugged into an electrical socket.
- 2 If the lamp has been in use, allow it to cool for approximately five minutes before proceeding.
- 3 To remove a tube already installed in the lamp, grasp the tube firmly in your hand and angle the tube out of the shade clip (M), approximately 15 degrees (P) and pull it straight out of the socket (N). Do not twist or turn the tube while removing it from the socket.
- 4 To install a tube in the socket, grasp the tube firmly in your hand, clip it into the shade clip (M) and push the tube straight into the socket (N) by applying pressure to the base of tube, until it "snaps" into place (O). Do not apply pressure to the glass end of the tube.
- 5 Plug the lamp into a standard 120V socket, and your lamp is ready for use.

### LAMP ASSEMBLY

- 1 Make sure that the lamp is not plugged into an electrical socket.
- 2 Remove the screw (H) from the upper pole (F). Insert the upper pole (F) into the shade and socket (G/J), re-insert the screw (H) and tighten using enclosed tool (I).
- 3 Twist and tighten the lower pole (D) into the hole (C) in the base (B) by hand.
- 4 To adjust lamp height, turn ring (E) between upper pole (F) and lower pole (D) counter-clockwise. Adjust upper pole to desired height, and tighten ring by turning clockwise.

Please note that in operation, OTT-LITE bulbs are not dimmable. Enjoy your OTT-LITE® Hampton Floor Lamp!

