

## 18W Broadway Floor Lamp

PS516T

### BULB INSERTION / REPLACEMENT

- 1 Make sure that the lamp is not plugged into an electrical socket.
- 2 If the lamp has been in use, allow it to cool for approximately five minutes before proceeding.
- 3 Rotate the shade (K) so that the notch in the base of the shade is positioned over the tab located on the socket assembly (G).
- 4 Remove the shade (K) by pulling it straight out from the socket assembly (G).
- 5 To remove a tube already installed in the lamp, grasp the tube firmly in your hand and angle the tube (L) out of the shade clip (J), approximately 15 degrees and pull it straight out of the socket. Do not twist or turn the tube while removing it from the socket.
- 6 To install a tube in the socket, grasp the tube firmly in your hand, clip it into the shade clip (J) and push the tube straight into the socket (I) by applying pressure to the base of tube, until it "snaps" into place. Do not apply pressure to the glass end of the tube.

- 7 To replace the shade (K), position it as indicated in the diagram, then push it back into the socket assembly making sure the shade "snaps" into place.
- 8 Rotate the shade to the desired position for use.
- 9 Plug the lamp into a standard 120V socket, and press the power switch (H).

### LAMP ASSEMBLY

- 1 Make sure that the lamp is not plugged into an electrical socket. Remove bolt (B), flat washer (M), lock washer (C) and wrench (A) from bag.
- 2 Screw upper pole (P) into lamp stem (Q).
- 3 Firmly insert stem of lamp (Q) into the hole located on the top of the base (N). Assume that the arrow at the top of the upper pole (P) points toward the front of the base (N). While holding stem into base of lamp, invert the lamp so the base is in the air.
- 4 Slide lock washer (C) onto bolt (B) and then slide the washer (M) onto the bolt. Place bolt, with lock washer and washer attached, into recessed hole located on the bottom of the base.
- 5 Using the enclosed wrench (A), tighten the bolt (B) securely by turning in a clockwise direction.
- 6 Slip dowel protruding from lamp base (D) into hole in upper pole (P).
- 7 Attach clips (O,T) onto lamps upper (P) and lower pole (Q) to retain electric wire.
- 8 To adjust lamp, turn nut screws (E, S) counter-clockwise to loosen. Adjust lamp to desired position (F) and tighten nut screws by turning clockwise.

Note: To use as a table lamp, attach clamp (R) to table, desk, shelf or other solid surface and insert dowel at end of lamp (D) into clamp.

Please note that in operation, OTT-LITE bulbs are not dimmable.  
Enjoy your OTT-LITE® Broadway Floor Lamp!

