



OTT-LITE
TECHNOLOGY®
The Science of Natural Light™

Instruction Manual



13W Weston Table Lamp

S8363R

ASSEMBLY

- 1 Align shade (B) with pole (E) and install thumbscrew (C) into shade. As needed, push wires into pole.
- 2 Push pole (E) into bottom of hole in base (D).
- 3 Align pole as desired then tighten set screws (F) with hex wrench (G) to secure pole to base.

BULB INSERTION/REPLACEMENT

- 1 Make sure that the lamp is not plugged into an electrical socket.
- 2 If the lamp has been in use, allow it to cool approximately five minutes before proceeding.
- 3 Loosen thumbscrew (C) and rotate shade (B) up for tube access, then re-tighten thumbscrew.
- 4 To remove a tube (A) already installed in the lamp, grasp it firmly in your hand and pull it straight out of the socket. Do not twist or turn the tube.
- 5 To install a tube in the socket, hold the tube (A) firmly near the base and push it straight into the socket until it “snaps” into place.
- 6 Return shade to its use position.

OPERATION

- 1 By tightening or loosening thumbscrew (C), pivot shade to desired position.
- 2 Depress the rocker switch (H) to turn the lamp on or off.

This lighting system is designed for use with OTT-LITE 13W tubes only. Use of other products voids the warranty and may result in damage to the hub or the lighting system

Please note that in operation, OTT-LITE tubes are not dimmable.

Enjoy your OTT-LITE® Weston Table Lamp!

