



Parts List	
Qty.	Description
1	Solar Sign Light Assembly
2	Security Head Screws
1	Security Driver Wrench

### Assembly Instructions

1. Carefully remove Solar Sign Light unit, fasteners and security driver wrench from protective packaging.
2. Safely place a 2-step stepstool or small a-framed ladder near post or surface to be mounted, to gain view of the mounting tabs on the unit, as the unit is positioned on the horizontal arm of the sign post.
3. Position the 2 side mounting tabs on the post so that the solar collectors are facing up, and the light underneath are unobstructed and able to illuminate a sign positioned below. Center on horizontal post over sign.
4. Attach the unit with the 2 security head screws, using the security driver wrench provided, by screwing them into the wooden post arm securely.
6. Solar Sign Light unit will charge during the day and remain illuminated for approximately 4 hours, when the sensor eye is activated.

Horizontal Arm of Sign Post (wooden)