



## 13W/230V Jupiter Table Lamp

48337R-UK  
(SL-599)

- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.
- Indoor use only.

### LAMP ASSEMBLY

1. Make sure the lamp is not plugged into an electrical socket.
2. Line up holes at the bottom of lamp (D) to base plate (C). Insert screw (A) through washer (B) and base (C) then tighten using enclosed tool.
3. To adjust lamp, turn nut screws (E, K) counter-clockwise to loosen. Adjust lamp to desired position and tighten nut screws by turning clockwise.

4. Close protective lid (G) to cover magnifier while not in use.

### BULB INSERTION/REPLACEMENT

1. Make sure the lamp is not plugged into an electrical socket.
2. If the lamp has been in use, allow it to cool for approximately five minutes before proceeding.
3. To remove a bulb (H) already installed in the lamp, grasp it firmly in your hand and pull it straight out of the socket. **Do not twist or turn the bulb while removing it from the socket.**
4. To install a bulb (H) in the socket, grasp the bulb firmly in your hand and push the bulb straight into the socket by applying pressure to the base of bulb, until it "snaps" into place (I, J). Do not apply pressure to the glass end of the bulb.
5. Plug the lamp into a standard 230V socket, and your lamp is ready for use.

Please note that in operation, OTT-LITE® bulbs are not dimmable.

Enjoy your OTT-LITE® Jupiter Table Lamp!

***This lighting system is designed for use with OTT-LITE TrueColor® bulbs only (model number 8R13CH-UK). Use of other products voids the warranty and may result in damage to the lighting system.***

