

18W Broadway Table Lamp

PS432K



BULB INSERTION / REPLACEMENT

- 1 Make sure that the lamp is not plugged into an electrical socket.
- 2 If the lamp has been in use, allow it to cool for approximately five minutes before proceeding.
- 3 Rotate the shade (K) so that the notch in the base of the shade is positioned over the tab located on the socket assembly (G) (refer to the diagram for proper shade position).
- 4 Remove the shade (K) by pulling it straight out from the socket assembly (G).
- 5 To remove a tube already installed in the lamp, grasp the tube firmly in your hand and angle the tube (L) out of the shade clip (J), approximately 15 degrees and pull it straight out of the socket. Do not twist or turn the tube while removing it from the socket.
- 6 To install a tube in the socket, grasp the tube firmly in your hand, clip it into the shade clip (J) and push the tube straight into the socket (I) by applying pressure to the base of tube, until it "snaps" into place. Do not apply pressure to the glass end of the tube.

- 7 To replace the shade, position it as indicated in the diagram, then push it back into the socket assembly making sure the shade "snaps" into place.
- 8 Rotate the shade to the desired position for use.
- 9 Plug the lamp into a standard 120V socket, and press the power switch (H).

LAMP ASSEMBLY

- 1 Make sure that the lamp is not plugged into an electrical socket.
- 2 Line up holes at the bottom of lamp (D) to base plate (C). Insert screw (B) and tighten using enclosed tool (A).
- 3 To adjust lamp, turn nut screws (E, M) counter-clockwise to loosen. Adjust lamp to desired position (F) and tighten nut screws by turning clockwise.

Please note that in operation, OTT-LITE bulbs are not dimmable. Enjoy your OTT-LITE® Broadway Table Lamp!

